

Features

- ✓ Original spare Part



Spare part - TB20 Base module Feed / Disconnect Module Slim

The base modules for the TB20 system are available as spare parts in sets of five.

All modules are delivered as complete assembled units with their front connector and base module (i.e., as a single assembly) and can be installed immediately.

General information

Order number	600-900-9BA01
Article name	Base module, for power and isolation module (set of five)
Scope of delivery	5 x base modules for power and isolation modules